

Lofting Instructions

- 1) Insert the (4) steel pins in the lower wood ends. Note: Wood pieces are drilled on one end only.
- 2) Position the rear stabilizer on the 3rd or 4th pin from the bottom of the posts.
- 3) Select and position the bed spring at the desired height on the other two bed ends.
- 4) Set the two wood ends complete with spring on the four pins.
- 5) Position the safety clips on alternate posts. One front and one rear.

